# NanoVNA-F Quick start guide - Firmware 0.2.x

By: BH5HNU
Date: 14 Jul 2020
Release: 3.0

Home Menu

DISPLAY
MARKER
STIMULUS
CAL
RECALL
CONFIG
STORAGE

TRACE
FORMAT
SCALE
CHANNEL
TRANSFORM
< BACK

Select a trace to modified the format, scale and more

TRACE 0
TRACE 1
TRACE 2
TRACE 3
< BACK

SELECT
OFF

LOGMAG
PHASE
DELAY
SMITH
SWR
> MORE
< BACK

POLAR
LINEAR
REAL
IMAG
RESISTANCE
REACTANCE
< BACK

S11 REFLECT
S21 THROUGH
< BACK

SCALE/DIV
REFERENCE POSITION
ELECTRICAL DELAY
< BACK

Keypad

S1P
S2P
LIST
< BACK

TOUCH CAL
TOUCH TEST
SAVE
ABOUT
BRIGHTNESS
LANGSET
< BACK

ENGLISH
CHINESE
< BACK

RECALL 0
RECALL 1
RECALL 2
RECALL 3
RECALL 4
< BACK

SELECT MARKER
SEARCH
OPERATIONS
SMITH VALUE
< BACK

MAXIMUM
MINIUM
SEARCH < LEFT
SEARCH > RIGHT
TRACKING
< BACK

LIN
LOG
Re+Im
R+Xj
R+L/C
< BACK

> START
> STOP
> CENTER
> SPAN
> EDELAY
< BACK

START
STOP
CENTER
SPAN
CW FREQ
PAUSE SWEEP
< BACK

Keypad

MARKER 1
MARKER 2
MARKER 3
MARKER 4
ALL OFF
DELTA
< BACK

TRANSFORM ON
LOW PASS IMPULSE
LOW PASS STEP
BANDPASS
WINDOW
VELOCITY FACTOR
< BACK

MINIMUM
NORMAL
MAXIMUM
< BACK

Keypad

CALIBRATE
SAVE
RESET
CORRECTION
< BACK

SAVE 0
SAVE 1
SAVE 2
SAVE 3
SAVE 4
< BACK

OPEN
SHORT
LOAD
ISOLN
THRU
DONE
< BACK

SAVE 0
SAVE 1
SAVE 2
SAVE 3
SAVE 4
< BACK




If calibration is available, the CAL status will be displayed.
Otherwise, it is hidden. C * is in the state where an unsaved calibration is applied(it disappears from memory when the power is turned off).

C0 to C4 Indicates that the saved calibration values are applied to one of the save locations. Saved or Unsaved will change when calibration data is properly saved.

The letters below C indicate that the following error terms have been applied.
D: Directivity, R: Reflection Tracking,
S: Source Match, T: Transmission Tracking and X: Isolation

| | Status | Red | Blue | |
|---|---|---|---|---|
| Charge | charging | Blink | OFF | After turning off the power, the blue light stays on for about 40 seconds, and then goes out. |
| | full | ON | OFF | |
| Discharge | discharging | OFF | ON | |
| | low battery | OFF | Blink | |

7 8 9 G
4 5 6 M
1 2 3 k
0 . ← x1
Done
Backspace & Exit